

Generac RTS Switches that are Compatible with Generac Air-cooled Generators 10/21/11



5837 - CorePower 6/7kW



5882 - Guardian 7/8kW



5883 - Guardian 9/10kW



5884 - Guardian 13/14kW



5885/6 - Guardian 16/17kW



5887 - Guardian 18/20kW

Only the following EZ Switches may be used with the generators shown. (The Generac Sizing Guide is incorrect for the 20kW.)



50A 8-Circuit Switch - Included



100A 10-Circuit RTS10EZA1,
Wire size 10ga
100A 12-Circuit RTS12EZA1,
Wire size 8ga
100A 14-Circuit RTS14EZA1,
Wire size 6ga, rated 65A
100A 16-Circuit RTS16EZA1,
Wire size 6ga, rated 65A



100A 12-Circuit RTS12EZA1,
Wire size 8ga
100A 14-Circuit RTS14EZA1,
Wire size 6ga, rated 65A
100A 16-Circuit RTS16EZA1,
Wire size 6ga, rated 65A



100A 14-Circuit RTS14EZA1,
Wire size 6ga, rated 65A
100A 16-Circuit RTS16EZA1,
Wire size 6ga, rated 65A



100A 16-Circuit RTS16EZA1,
Wire size 6ga, rated 65A

No EZ Switches are compatible.

Wire sizes on the 30-ft. whips of the EZ Switches are incompatible with the 5887 Guardian 18/20kW Generator.



100A RTSX100A3 Non Service Nexus
200A RTSX200A3 Non Service Nexus



100A RTSX100A3 Non Service Nexus
200A RTSX200A3 Non Service Nexus



100A RTSX100A3 Non Service Nexus
200A RTSX200A3 Non Service Nexus



100A RTSX100A3 Non Service Nexus
200A RTSX200A3 Non Service Nexus



100A RTSX100A3 Non Service Nexus
200A RTSX200A3 Non Service Nexus



100A RTSD100A3 Service Disconnect Nexus
200A RTSD200A3 Service Disconnect Nexus



100A RTSD100A3 Service Disconnect Nexus
200A RTSD200A3 Service Disconnect Nexus



100A RTSD100A3 Service Disconnect Nexus
200A RTSD200A3 Service Disconnect Nexus



100A RTSD100A3 Service Disconnect Nexus
200A RTSD200A3 Service Disconnect Nexus



100A RTSD100A3 Service Disconnect Nexus
200A RTSD200A3 Service Disconnect Nexus



200A RTSJ200A3 Whole House Service Entrance with 16-Circuit Load Shed



200A RTSJ200A3 Whole House Service Entrance with 16-Circuit Load Shed



200A RTSJ200A3 Whole House Service Entrance with 16-Circuit Load Shed



200A RTSJ200A3 Whole House Service Entrance with 16-Circuit Load Shed



200A RTSJ200A3 Whole House Service Entrance with 16-Circuit Load Shed



200A 5449 GenReady, use up to 125A 30kW



200A 5449 GenReady, use up to 125A 30kW



200A 5449 GenReady, use up to 125A 30kW



200A 5449 GenReady, use up to 125A 30kW



200A 5449 GenReady, use up to 125A 30kW

